lavatools JAVELIN PRO CALIEODNIA USA



O1) PROBE 18/8 food grade stainless steel

03 LCD backlit antifog display

02 TOUCH PAD for power saver function

- 04) TOUCH PAD for backlight and more
 - 05) MAGNET for easy storage
 - 06 FOOD SAFE antimicrobial coating

STABILIZATION ALERT

Insert the probe into your food and hold the # icon. The word HOLD will start blinking and after a few seconds, a double chime will sound when the temperature has stabilized.

The stabilized temperature remain on the display as long as you are holding the \circledast icon. Release your finger to return to normal.



MAX/MIN

Double tap the * icon to display the maximum temperature for current session. Tap * again for the minimum temperature. To exit. tap * again.

Hold the * icon during MAX/MIN to clear values.

POWER SAVER

Hold the JWEIN icon to enable power saving mode. This will disable the backlight and reduce power consumption.

Press and hold the PRO icon again to exit this feature.



CHANGING THE BATTERY

When the display shows "ERROR" and the a icon, it's time to switch out your battery. Fully retract the probe and twist open the battery door with a coin.

Carefully remove existing battery and insert a new CR2032 with the positive (+) pole up.



ADDITIONAL INFORMATION

Sleep Mode

If left on and idle for more than 60 minutes, the Javelin PRO will automatically go to sleep. Simply tap the touch pad to wake the device.

Antifog Display

The display is coated in a hydrophobic agent to keep the readout fog-free even when measuring steaming liquids. For this reason, we do not recommend scouring cleaning products as it will strip the coating.

Magnetic Backing

The Javelin PRO has a built-in magnetic backing to allow for convenient storage. Magnetic backing may not work on stainless steel surfaces.

Antimicrobial Coating

Silver-based antimicrobial additive is impregnated into the plastic shell to inhibit the growth of pathogens. Efficacy is rated at 99% or greater.

Tapered Sensor Tip

The ultra-sensitive thermistor sensor is located at the tip of the probe, requiring a minimum insertion distance of 0.25" (5mm).

PERSONAL IZATION

Personalize your Javelin PRO using switches found inside the battery bay. You can disable and re-enable various functions by toggling their respective switches. You must turn off the device

| to have these changes apply. | | | |
|------------------------------|--------|----------|---------------------|
| | 1 | 2 | 3 |
| | toggle | toggle | toggle |
| | C°/F° | auto-off | stabilization alert |

ACCUPACY TEST

To check the accuracy of your Javelin PRO, we recommend using an ice bath test. To create an iced bath, fully pack a large cup with crushed ice. Next. fill 3/4 of the cup with purified water. Let the slurry sit for a brief moment and give it a guick stir to allow the temperature to equalize throughout. Insert the tip of the probe into the very center of the cup and stir gently. In 3 to 4 seconds, the display will read within 1°F (0.5°C) of 32°F (0°C).

TROUBLESHOOTING

WON'T NO DISPLAYING CHANGE SWITCH ON BACKLIGHT "ERROR" $\mathbb{C}^{\circ}/\mathbb{F}^{\circ}$

retract and extend ensure it probe or change saving r battery disab

ensure battery saving mode is disabled battery is running low, change batteries use switch 1 to switch between C°/ F° DEVICE ASLEEP

RESTORE FACTORY SETTINGS

downwards



DOESN'T BLINK

"HOLD"



tap on touch pad turn off device and position all personalization switches

make sure to hold the touch pad long enough use switch 3 to activate stabilization alert



LISE & MAINTENANCE

. Do not put the device in the dishwasher

- Do not insert the probe all the way to the plastic collar
- Always measure at the center of the meat, avoid hitting bone or hard cartilage.
- Prevent bacterial growth by wiping down the probe after each use
- \bullet Clean the body with soft damp cloth. Do not use solvents or scouring agents



This device is exclusively intended for the field of application described in this manual. It should only be used as described within these instructions. Abuse, water damage, modification, or accidental breakage to the product will void all warranty.

SAFFTY WARNING

- Never leave the device in the oven
- Never place probe directly over fire
- · Never immerse the device in liquid for any period of time
- . Keep the device and battery out of reach of children
- Do not subject the device to extreme temperature, vibration, or shock
- Batteries must not be thrown into the fire, short-circuited, taken apart or recharged



come visit us for more info